



**BUOYANCY
COMPENSATOR
OWNER'S MANUAL**

2024

CE CERTIFICATION INFORMATION

ECLIPSE / INFINITY / EVOLVE / EXPLORER BC SYSTEMS

CE TYPE APPROVAL CONDUCTED BY:

Polski Rejestr Statków S.A.
Al. Gen. J.Hallera 126
80-416 Gdańsk, Poland
Registration No.: 1463
Certificate No.: CW/PPER/3/07/2024
EN 1809:2014+A1:2016

CE CONTACT INFORMATION

Halcyon Dive Systems
24587 NW 178th Place
High Springs, FL 32643 USA

AUTHORIZED REPRESENTATIVE IN EUROPEAN MARKET:

Halcyon Europe Ltd.
Wodnika 50
80-299 Gdańsk, Poland

REEL Diving
Kråketorpsgatan 10
431 53 Mölndal

HALCYON

BUOYANCY COMPENSATOR

OWNER'S MANUAL

TRADEMARK NOTICE

Halcyon® and BC Keel® are registered trademarks of Halcyon Manufacturing, Inc. Halcyon's BC Keel and Trim Weight system are protected by U.S. Patents #5855454 and 6530725b1. The Halcyon Cinch is a patent-pending design protected by U.S. and European law. Halcyon trademarks and pending patents include Multifunction Compensator™, Cinch™, Pioneer™, Eclipse™, Explorer™, and Evolve™ wings, BC Storage Pak™, Active Control Ballast™, Diver's Life Raft™, Surf Shuttle™, No-Lock Connector™, Helios™, Proteus™, and Apollo™ lighting systems, Scout Light™, Pathfinder™ reels, Defender™ spools, and the RB80™ rebreather.

WARNINGS, CAUTIONS, AND NOTES

Pay special attention to information provided in warnings, cautions, and notes accompanied by these icons:



A WARNING indicates a procedure or situation that, if not avoided, could result in serious injury or death to the user.



A CAUTION indicates any situation or technique that could cause damage to the product, and could subsequently result in injury to the user.

WARNING

This manual provides essential instructions for the proper fitting, adjustment, inspection, and care of your new Buoyancy Compensator. Because Halcyon's BCs utilize patented technology, it is very important to take the time to read these instructions in order to understand and fully enjoy the features that are unique to your specific model. Improper use of your BC could result in serious injury or death.

COPYRIGHT NOTICE

This owner's manual is copyrighted, all rights reserved. It may not, in whole or in part, be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine readable form without prior consent in writing from Halcyon Manufacturing, Inc.

©2018 Halcyon Manufacturing, Inc.

CONTACTING HALCYON

Halcyon Dive Systems
24587 NW 178th Place
High Springs, FL 32643 USA

386.454.0811
800.HALCYON
386.454.0815 (fax)
info@halcyon.net www.halcyon.net

GENERAL

PRECAUTIONS & WARNINGS

*Before using this Buoyancy Compensator (BC), you must receive instruction and certification in SCUBA diving and buoyancy control from a recognized training agency. Use of SCUBA equipment by uncertified or untrained persons is dangerous and can result in serious injury or death.

*Read this owner's manual completely before attempting to use your BC, and become familiar with it first in a controlled environment, such as a swimming pool, in order to weight yourself properly and to become comfortable with using its many features and adjustments.

*Before every dive, perform a complete pre-dive inspection according to the procedure prescribed in this manual, to ensure that all components are functioning properly and no signs of damage or leaks are present. If your BC is not functioning properly or is damaged, remove it from service until it can be repaired by an authorized Halcyon Dealer.

*Before every dive, as part of your pre-dive inspection, ensure that all bolts and attachment components of your BC system are securely connected. This includes the Single Tank Adapter fasteners to assure your cylinder and STA are secured to the backplate.

*Your BC is not a lift bag. DO NOT use it to bring heavy objects to the surface. Doing so may cause permanent damage to the BC, and could also result in an uncontrolled ascent.

*DO NOT over inflate your BC. Control all ascents. A rapid, uncontrolled ascent may cause arterial gas embolism or decompression sickness and could lead to serious injury or death.

*In the event of an uncontrolled ascent, it is important to immediately begin venting air from the BC. Continue venting air to slow your ascent rate if neutral buoyancy cannot be reestablished.

*In an emergency such as an out-of-air situation or uncontrolled descent, it is important to remove and jettison weight immediately. DO NOT depend solely on using your BC's power inflator to lift you to the surface.

*DO NOT inhale from your oral inflator. The BC may contain harmful contaminants or gasses, which could cause suffocation, serious injury, or infection of the lungs.

*Disassembly, repair, or lubrication must not be attempted by persons who are not factory-trained and authorized by Halcyon. Unauthorized service will render the warranty null and void.

*Factory prescribed service for this BC should be performed at least once annually by an authorized Halcyon Dealer. Annual service consists of a complete overhaul of the power inflator, and a general air leak inspection of the bladder and valve connections.



WARNING: Your Buoyancy Compensator (BC) is NOT a lifejacket; it does not guarantee a head-up position of the wearer at the surface. It does not meet U.S. Coast Guard regulations for a life preserver or personal flotation device (PFD). If you become unconscious in the water without a buddy present to immediately assist you, you may suffer serious injury or death from drowning.

This product is used only for buoyancy management of certified scuba divers, all other uses are excluded. Your buoyancy compensator is primarily designed to help you maintain neutral buoyancy while in a comfortably balanced, face-down swimming position underwater. It is also designed to provide you with flotation so that you can rest on the surface, but it is not designed to function as a life preserver or personal flotation device (PFD). In order to meet U.S. Coast Guard regulations, a PFD must be designed so that it automatically directs you to a face-up position and holds your head out of the water on the surface. The design characteristics of a personal flotation device are therefore different from those of a buoyancy compensator. The ability of any flotation device to float you in a face-up position can also be affected by other diving equipment you wear, including a cylinder or exposure suit, and whether it can be inflated before you lose consciousness.

For this reason, it is important to always dive with a buddy, and maintain close proximity with them at all times. Do not depend on any flotation device to hold your face above the surface in the event that you are rendered unconscious in the water while diving.



WARNING: While this manual provides some basic guidelines for certain buoyancy control techniques, it is not a substitute for training from an active teaching status, professional diving instructor. Failure to weight yourself properly may create a hazardous condition that could lead to serious injury or death. If you are unsure how to weight yourself in order to achieve optimum buoyancy underwater and on the surface, do not dive until you have obtained the necessary instruction from your diving instructor or an authorized Halcyon Dealer.

If you have any questions regarding your Buoyancy Compensator or these instructions, contact your Halcyon Dealer or Halcyon directly at: (386) 454-0811.

This product is designed to last for 5 years after the date of manufacturing under normal use and conditions. Disposal should be conducted in alignment with local authorities.

Halcyon Manufacturing Inc., 24587 NW 178th Place, High Springs, Florida, 32643, USA declare that a sample of the product listed above has been tested for CE marking according to:

Regulation: EU 2016/425

Report Date of Issue: 09-Mar-2018

Standards: EN 1809:2014+A1:2016

The test reports show that the product fulfills the requirement in the EU Regulation, BP 601 38034 001.

In addition we confirm compliance with legal requirements for harmful substances in Germany (e.g. ban of PCP, Chromium-V I) and that requirements for polyaromatic hydrocarbons (PAH) to AfPS GS 2014:01 PAK are also met. The manufacturer confirms that the PPE is made from materials which do not affect the health or hygiene of the user. We also confirm that the PPE is made of materials that under foreseeable conditions of normal use or by degradation do not release substances generally known to be toxic, carcinogenic, mutagenic, allergenic, toxic to reproduction or otherwise harmful.



TABLE OF CONTENTS

FITTING YOUR HALCYON BUOYANCY COMPENSATOR	07
FINE-TUNING YOUR BC SYSTEM	09
HALCYON CINCH QUICK-ADJUST HARNESS	12
INSTALLING THE CINCH SYSTEM	15
DIVING THE HALCYON BC SYSTEM	20
PRE-DIVE BC SYSTEM INSPECTION	24
BC SYSTEM CARE AND MAINTENANCE	25
APPENDIX 1: BC SYSTEM COMPONENT CHECKLIST	26
APPENDIX 2: HALCYON WARRANTY INFORMATION	28
APPENDIX 3: HALCYON WARRANTY INFORMATION	30

FITTING


YOUR HALCYON BUOYANCY COMPENSATOR

The Halcyon Buoyancy Compensator system provides superior buoyancy control and trim adjustment for divers in any underwater environment. Each component of the BC system: the proper buoyancy wing, alternative lift device, weighting system, and Secure Harness works together to provide you with safe, efficient control of your gear while under water and on the surface. The BC harness system is adjustable to fit all body types, providing for a much more precise fit than jacket-style BCs.

The Halcyon Buoyancy Compensator has two primary forms of adjustment. The classic adjustment system involves a semi-permanent fitting in which the diver tunes the harness to the appropriate size based upon their physical size or stature and thermal protection. Meanwhile, the patent-pending Halcyon Cinch System allows the diver to adjust the harness quickly, fine tuning it for each dive regardless of the thermal protection worn. The classic system can be upgraded by purchasing a Cinch Upgrade from your Halcyon dealer. Both systems are discussed in detail with the quick-adjust Cinch outlined later in this text.

To properly fit your Secure Harness before first use, begin by suiting up with the same thermal protection that you will use with your BC. If you plan to dive with a drysuit, make sure to include all undergarments. In addition to the thickness of the drysuit, a full set of thermal undergarments can add considerable bulk and have a dramatic impact on the sizing of the harness.

Fitting Your Buoyancy Compensator – Classic Semi-permanent Fitting



You can adjust the Halcyon BC Secure Harness without the use of special tools by adjusting the fasteners along the back of the backplate and on the crotch strap (image 1).



To adjust the shoulder straps, loosen the triglide fasteners on the back of the backplate where the webbing feeds through the slots (image 2).

Using equal amounts of webbing from both sides of the waist belt, adjust the straps so that several fingers can fit under the webbing along your shoulders (image 3). The shoulder straps need to be loose enough to be comfortable with your thickest amount of thermal protection. The fit of the harness should facilitate easy doff/don, both in water and out of water, yet still remain snug enough so that your tanks are secure while stage bottles clipped off to the top D-ring stay close to the chest.





To finalize the fit of the harness shoulder straps, loosen the straps enough to allow easy movement of the backplate. Position the backplate for proper tank position, with the top of the backplate high enough to touch by reaching behind your head with either hand; if you can touch the backplate, you should be able to reach your valves when your rig is fully assembled (see image on the left). With the backplate in position, tighten up the arm straps until you are able to fit two or three fingers underneath the strap. You should be able to easily slide the straps off of either shoulder. Be careful not to leave excessive slack in the harness straps. An exceedingly loose-fitting harness will allow the backplate to ride low on your back, making it nearly impossible to reach your valves.

The crotch strap should be comfortable and allow you to reach your tanks. The waist belt should fit as snug as is comfortable. Do not overtighten the waist belt so much as to restrict breathing. When adjusting the waist belt, make sure to set the buckle so that it is off to your right side. With the buckle in this position, the crotch strap is unable to accidentally open the buckle. The waist belt buckle (and/or another buckle) can be used to hold your primary light canister in place.

To adjust the crotch strap, buckle the waist strap without running it through the crotch strap. Now pull the crotch strap up to the waist belt. Set the length so that the top of the crotch strap loop extends a half-inch (12mm) over the top of the waist belt.

While standing on land, your BC should be snug but not uncomfortably tight. In the water your harness should be snug enough to prevent notable motion of the cylinder as you change orientation, but not too tight so as to bind or restrict your complete range of shoulder and arm movement.

FITTING YOUR BUOYANCY COMPENSATOR - CINCH QUICK-ADJUST DESIGN

Adjustment of the Secure Harness while wearing the Cinch is quick and easy. Following similar guidelines, begin your first sizing in the exposure suit you will be diving in. Once finished, check placement of the D-rings as noted in the previous section and be sure to trim the extra webbing after you've determined the best size range for your Cinch harness and quick adjust crotch strap.

- **To Tighten the Harness:** While using both hands, grasp the ends of the waist band webbing and pull up and outward (at roughly 45 degrees) from the body.
- **To Loosen the Harness:** Grasp the webbing at the shoulder straps just above the waist. Push the harness out and up slightly from your waist.

Detailed information on sizing and adjustment of the Cinch design can be found later in this text.

FINE-TUNING YOUR BC SYSTEM


The BC harness is the model of simplicity. The Secure Harness utilizes one D-ring on each side of the chest, avoiding the unnecessary clutter of multiple attachments. One D-ring is located on your left hip and single D-rings are placed on the front and back of the BC crotch strap. The hip D-ring is used to attach a pressure gauge, stage bottles, or small tools during a dive.

The knife is placed in a sheath on the waist belt left of the crotch strap, where it can be quickly deployed with either hand. The knife is small and designed as a tool for cutting line. Two backup lights are attached, one to each of the two chest D-rings. These lights are held to the strap by EDPM rubber bands. This location puts the lights in a streamlined position against your chest while remaining completely accessible.

Once you have properly sized your Secure Harness, you will want to fine-tune the position of the five D-rings. The shoulder D-rings should be positioned relatively high on the shoulder straps, especially if you plan to utilize stage bottles in your diving. If the D-rings are too low, the stage bottles will hang too far away from your body, causing significant drag and possibly damaging marine environments. The shoulder D-rings should also be high enough to allow for proper storage of your back-up lights and to allow for ease of use of your wing's inflator hose to adjust trim and buoyancy, yet not so high that you can't clip an item off with the same-side hand as the clip.

To position the shoulder D-rings, extend your arms straight out to the side, parallel to the ground. Bend at the elbow and bring your thumb straight to the shoulder strap. The center of your thumb should intersect the center of the D-ring (figure 1 on the following page). Next, reach across your body to (or almost to) your left shoulder with your right arm (figure 2 on the following page). Make sure the right-side D-ring doesn't pinch between your arm and chest. Do the same with your left. If either D-ring pinches, adjust it upwards.

The waist D-ring is used for clipping off the SPG and for stage bottles. To position the waist D-ring, run your left thumb straight down your left side until it hits the waist strap. Your thumb should intersect the D-ring, very close to your hip bone. The position might need to be adjusted after your first dive with your BC system. In water, practice clipping/unclipping the SPG and, if you wear stage bottles, have your buddy check the position of the tanks. You do not want the waist D-ring positioned so far back that you can't comfortably clip or unclip your SPG, nor so far forward that a buoyant stage would become a



hindrance or cause excessive drag.

The rear crotch D-ring is generally used for storing gear not used very often, such as reels or lift bags. This D-ring needs to be low enough that you can clip/unclip gear (and not be blocked by the bottom of the tanks), yet high enough that the gear does not hang down too far. Typically, position the rear D-ring one hand-width down from the bottom of the backplate (figure 3 below).

The front crotch D-ring is only used with a tow-behind scooter. Gear should never be clipped to this D-ring, as it will hang in the slipstream and pose significant entanglement hazards.



Figure 1



Figure 2



Figure 3




Figure 4



Figure 5

FINAL ASSEMBLY OF YOUR BC SYSTEM

Final assembly includes attaching the Halcyon Single Tank Adapter (STA) to the wing and backplate with the two supplied fasteners/bolts. If you are using the 6-lb. Convertible Weight, be sure this is in position in the STA (figure 4 above) and be sure the straps are correctly configured on the STA. Place the wing on top of the STA through the bolts, then the backplate on top of the wing. Tighten both bolts and fasteners securely. Slide the cam straps over your cylinder and tighten at desired position in relation to the cylinder's valve (figure 5 above). When diving with doubles, the backplate is bolted to the cylinders with an Explorer or Evolve buoyancy wing sandwiched between the backplate and cylinders. The bolts on the cylinder bands thread through the two grommets on the wing (see images on the following page).



WARNING: The cam straps may stretch after they become wet. Always wet the straps prior to making the final adjustment, and apply enough tension to ensure that the cylinder is held completely secure. Ensure the bolt fasteners between the STA and the backplate are secure. Test these connections before every dive. If the cylinder were to slip free from the BC while you are diving, you may lose your air supply, which could lead to serious injury or death.



WARNING: Halcyon BC wings are specifically designed for either single or double cylinders. Always use the appropriate wing for the designated cylinder type(s). Failure to use the appropriate amount of lift for a given cylinder configuration can result in negative buoyancy, which could lead to serious injury or death. Always test your fully rigged and weighted BC system in a controlled environment such as a pool before attempting a dive.



HALCYON

CINCH QUICK-ADJUST HARNESS

Halcyon has a long history as an industry leader in BC design, offering simple and robust designs for more than a decade. One of our innovations is the Halcyon Cinch (patent pending). The Cinch redefines what it means to dive a backplate, building upon a platform of simplicity while providing unprecedented security and ease of adjustment. Halcyon developed the Cinch to save divers time and effort while sizing, fine-tuning and resizing your diving harness. Now you can change suits or divers and adjust the Cinch in a flash; all this without compromising the harness integrity or our trademark, continuous piece of webbing. Adjustments to the Halcyon Cinch occur by simply sliding the harness through a unique, patent-pending assembly. Now divers can easily adjust the fit of their plate in or out of the water—a simple push or pull is all it takes. If you need a quick way to get out of your dive system; if you regularly change the thickness of your diving suit; or if you train new students in Halcyon rental equipment, this new invention will change the way you dive.

DIVING WITH THE CINCH

If you are installing a Cinch upgrade, be sure to use new webbing and check that it is free of blemishes. This manual contains detailed assembly instructions to assist in properly fitting the Cinch upgrade.

ADJUSTMENT OF THE CINCH HARNESS

Adjustment of the Secure Harness while wearing the Cinch is quick and easy. Be sure to trim the extra webbing once you've determined the best size range for your Cinch harness and quick-adjust crotch strap. The Cinch harness can be adjusted in or out of the water and can be used with single or double cylinders. It is best to adjust the Cinch while the cylinders are supported, such as sitting on a bench, table edge, tail gate, or similar.

- To Tighten the Harness: While using both hands, grasp the ends of the waist band webbing and pull up and outward (at roughly 45 degrees) from the body (see figure 6).
- To Loosen the Harness: Grasp the webbing at the shoulder straps just above the waist. Push the harness out and up slightly from your waist (see figure 7).

It is possible to overtighten the harness. If desired, a triglide can be put in place as a “stopper” on the webbing to allow a full stop of sizing when the harness has reached it's desired fit (see figure 9). (Please see Cinch assembly instructions for additional detail.)

- Left D-Ring: Adjustment of the left hip D-ring position can be done by moving the triglide/D-ring forward or backward on the assembly .
- Right Light Retainer Assembly: Attachment of the light assembly will be necessary if you choose to dive a waist-mounted canister light with the Cinch. Consult the Cinch installation section for full instructions.
- Adjustment of the quick-adjust crotch strap is done quickly by moving the webbing through the quick-adjust, slide buckle as shown in figure 8. A rear D-ring is included on

the crotch strap; you may remove this if you choose.

- BC Storage Pad: Undo the bottom bolts to allow access to the pocket if storing a lift device in the backplate storage pad.
- BC Shoulder Pads: Adjustment of pad placement is done by moving the velcro tabs up or down in the corresponding slots on the pad then attaching the tabs around the harness.
- Diving Double Cylinders: You may need to use the Cinch Bolt Extender on the lower tank band bolt. We suggest you check this when you first set up your Cinch assembly to your backplate if using double cylinders. We do not suggest using the Bolt Extender on the top tank band or if you are not diving a Cinch assembly.



Figure 6



Figure 7



Figure 8

A triglide may be put into place to act as a sizing guide to prevent over tightening the harness. Figure 9 shows the optional triglide placement to prevent over tightening. On the right, in Figure 10 is pictured without.



Figure 9



Figure 10


Complete instructions on installation and sizing of the Cinch and quick-adjust crotch strap can be found at the end of this Cinch manual section.

HALCYON CINCH COMPONENTS (see image on the following page to match up items with numbers)

1. Cinch Adapter Plate - High-quality, molded ABS plate is uniquely designed to fit the contours of your Halcyon backplate, providing unprecedented adjustability without the risk of quick-release buckles or the hassle of dangling webbing.
2. D-Ring Assembly - Allows the secure harness webbing to slide freely without affecting the position of the left-hip D-ring.
3. Doubles Bolt Extender - Extends a short bottom bolt, allowing the Cinch System to fit a variety of double tanks. Available in metric (5mm) or imperial (5 16/18).
4. Bolts Kit - Comes with four (two 1/4 - 20 by 3/8, two 1/4 - 20 by 5/8) SS bolts with weld

mate nuts. Two wing nuts also come with the Infinity System.

5. Light Retainer Assembly - Allows the secure harness webbing to slide freely without affecting the position of a light mounted to the right hip.
6. Weight Pocket Attachment (Pair) - Secures the Halcyon ACB integrated weight system to the harness and allows the secure harness webbing to slide freely without affecting the placement of the ACB.
7. Quick-adjust Crotch Strap - Features a quick-adjust, sliding buckle for easy crotch strap sizing.



INSTALLING THE CINCH SYSTEM

If you are upgrading to the Cinch, it is important that you start with new harness webbing when retrofitting the Halcyon Cinch to an older backplate. New webbing allows the Cinch to slide freely whereas old webbing will catch at the indents left from previous triglide/D-ring placement.

- Remove all webbing accessories starting with the waist belt, including the SS waist buckle, left D-ring/triglide, ACB weight pockets, and knife sheath.
- Remove the triglides from behind the plate and pull the webbing through the lower back plate slots.
- Finish removing the webbing from the top slots after removing the D-rings.
- Start with a new set of webbing that is free from indents or blemishes.
- Align the Cinch plate assembly to the backplate and attach it using the provided bolts. The Light Retainer Fixture attaches using the right bolt, which also holds the Cinch to your backplate. If using the the light fixture, secure the left (3/8") bolt first. You can insert the right bolt when installing the light fixture. If you are not using the light fixture, you may secure both bolts (3/8") at this time (figure 11 & 12).




Figure 11



Figure 12

ATTACHING THE D-RING (LEFT) AND LIGHT RETAINER ASSEMBLY (RIGHT)

The D-ring and light-retainer assemblies allow you to adjust your webbing freely without affecting the position of the light and/or D-ring.

Left (as worn by the diver): You will be using the left, outermost slot of the Cinch plate to attach the d-ring fixture. Thread the webbing of the D-ring through the outer Cinch slot and then through both sections of the triglide. Adjust length as desired. After the waist band is assembled, feed the waist belt through the slot on the D-ring holder (figure 13 &14).

Right (as worn by the diver): If you are using a waist mounted light canister, it is necessary to attach the light retainer assembly. In this case you will be using the right, outermost slot on the Cinch to secure the light assembly. The same bolt secures both the assembly piece and the Cinch plate.



Figure 13



Figure 14



'To Install the Light Retainer Assembly:

- Insert the rigid webbing grommet hole through the right outer slot on the Cinch (figure 15).
- Fold the webbing and align the grommet with the hole on the Cinch. Secure both items with the 5/8" bolt & tighten snugly (figure 16).
- Thread the waist band webbing through the backplate slots.
- Slide the buckle fixture on to the waist band with the open end of the buckle facing the backplate. The buckle is secured to the tab of webbing protrudes from the attached light fixture (figure 17).
- The buckle can be adjusted and the light positioned according to individual preference (figure 18).



Figure 15



Figure 16



Figure 17



Figure 18

ATTACHMENT OF ACB INTEGRATED WEIGHT POCKETS TO THE CINCH

- Insert the ACB attachment webbing through the triglide on the pocket (figure 19). Adjust ment of this triglide position determines placement on the waist. The extra webbing should be tucked into the slot after attachment (figure 20).
- Insert the webbing grommet hole through the (R or L) outer slot on the Cinch (figure 21).
- Fold the webbing and align the grommet with the hole on the Cinch. Secure both items with the 5/8" bolt & tighten snugly (figure 22).
- Thread the waist band webbing through the ACB slots (figure 23).

Repeat the process on the opposite side, then reassemble your harness & components.



Figure 19



Figure 20



Figure 21



Figure 22



Figure 23

FINAL ASSEMBLY

Verify that the Cinch is secure on the backplate with the light, ACB weight pockets, or D-ring fixtures attached as desired. Ensure the webbing is threaded properly through the Cinch (see images to the right) and any installed fixtures. Install the knife pocket and waist buckle to the desired positions. Trim excessive webbing from the ends of the waist but remember to leave room for various suit/undergarments.



INSTALLING THE QUICK-ADJUST CROTCH STRAP

If retrofitting an existing Halcyon plate, unweave the crotch strap from the tri-glide. Remove the tri-glide/D-ring and remove the webbing from the backplate. Run the end of the webbing into the quick-adjust slide buckle with the buckle curve facing downward as shown. Thread the webbing through the backplate from the front to the back of the plate as shown (figure 24). The D-ring is placed between the tri-glide and webbing after threading it through the plate, as seen in figure 25, so it will be secured under all the webbing. Then thread the webbing through the quick-adjust triglide, then back through both slots of the standard triglide (figure 26-27). Adjust the length as needed to insure a proper fit. The recommended D-ring location is roughly a hand's width from the bottom of the backplate. Adjusting the triglide close to the backplate as discussed above provides additional room to refine the quick-adjust buckle position.



Figure 24



Figure 25



Figure 26



Figure 27

POSITIONING THE QUICK ADJUST

Once the crotch strap length is sized correctly, you may find the crotch strap quick buckle adjust sits incorrectly, e.g. too far from the plate (figure 28). To correct this, maintain the proper length of crotch strap and move the quick adjust buckle up toward the backplate, creating a loop of webbing behind the triglide. Pull the webbing through the triglide until the extra webbing is all the way through and the quick adjust buckle remains an appropriate distance from the backplate (figure 29). Keep the triglide/D-ring and the quick adjust fairly close together, then thread

the webbing back through the triglide. Cut off excess webbing “tail” leaving enough for future length adjustments as necessary (figures 30-31).



Figure 28



Figure 29



Figure 30



Figure 31

Confirm that your hardware is in the correct place by trying on your backplate. D-ring should sit appropriately from the bottom of the plate. Sizing of the quick-adjust crotch strap is now done quickly by sliding the webbing through the quick-adjust buckle.



Any excess webbing tail may be tucked back through the backplate and secured with a section of the EPDM band off the crotch strap if it's necessary to keep it longer, e.g., when using the System in Rental or Training. You will need to undo this when using the quick-adjust, so be aware of this when sizing on a new diver.



DOUBLES BOLT EXTENDER

The Cinch can easily be used with double cylinders. If you have shorter bolts on any set of tank bands, you may need to use the extension bolt on your bottom tank band. Simply screw the extension bolt to the bottom bolt of the tank band (snugly) onto the bottom tank band, and set up your backplate as normal. Note: It is not desirable to use the bolt extender on the top bolt.



INSTALLATION OF HALCYON DELUXE HARNESS PADS

Halcyon offers a Deluxe Harness upgrade featuring a set of shoulder pads and a backplate pad for the ultimate comfort while diving in thinner exposure suits. Our deluxe shoulder pads allow the diver to customize D-ring position by way of movable velcro tabs (figure 32-33). The backplate pad also features a BC Storage pocket allowing the diver to carry a surface marker or lift bag in a streamlined position.

To Install Your Shoulder Pads:

Please note that the shoulder pad sits below the harness and is secured by three Velcro tabs on each shoulder. These tabs can be adjusted up or down to customize their location and make room for chest D-rings.

1. Open the large Velcro tab which is positioned at the end of the shoulder pad. Thread this tab between the harness and the backplate slot. The Velcro should be facing up and run through the same backplate slot as the harness. Secure the large Velcro tab. The end of the pad should be attached to the plate.
2. Position the harness strap above the shoulder pad and line up the small vinyl tabs so they fit appropriately while allowing room for the D-ring and providing a secure attachment for bottom of the pad.
3. We recommended you fold the “loop” (softer part of the Velcro) side of the Velcro in half to create a smooth surface which simplifies insertion of the tabs through the slot on the shoulder pad. Do not force the vinyl tab through the slots in the shoulder pad.
4. You can place the Velcro tabs along any of the slots in the shoulder pad but you should verify the pad is secured evenly with the D-ring and accessory attachments (EPDMbands for Scouts, etc.) in their proper position.



Figure 32



Figure 33

To Install the Backplate Pad:

1. Secure the top two holes on each side of the plate by inserting the nut in the hole on the face of the backplate. Wrap the tab of the pad around the plate and secure the bolt by screwing into the nut that rests in the backplate mounting hole.
2. Repeat step one for the top two holes on each side of the backplate.
3. The third set of bolts is usually attached by folding the tab under the pad so it sits on the face of the backplate. This provides additional room for lift devices. If you are not using lift devices you may use the same method as detailed in step one. If you are using the storage pocket in the pad the nut is sandwiched between the tab and the pad and is aligned with the third backplate hole. The bolt runs from the back side of the plate and attaches to the nut. This is also the recommended method of attachment if you will be using a Cinch Quick-adjust harness.
4. The final bottom bolts (at the bottom of the plate) should be left undone if using the backplate Storage pak. If you will not be using the Storage Pak you can attach the bottom tabs.
5. Be sure you check your bolts are securely fastened. It is recommended to check the tightness of your bolts regularly, particularly for the first few dives after assembly.

DIVING

THE HALCYON BC SYSTEM

USING A LIFT DEVICE WITH YOUR BC SYSTEM

The optional BC Storage Pak (figure 34) provides stealth storage for alternate lift and signaling devices. Storing devices in the Pak eliminates the possibility of accidental damage or entanglement on land, in a boat, or in the water. The Storage Pak bolts onto your rigged Secure Harness backplate with the eight supplied bolts. Alternate lift devices are carried in the Pak folded flat, with the snap connected to the left waist D-ring. To deploy the device, simply detach the bolt snap with your left hand and then pull down and to the left. Once the device has cleared the Pak it can be inflated using the low-pressure hose from your BC inflator or by using a low-pressure hose connected to a separate air source such as a dry suit inflator (figure 25).



Figure 34

The BC Backplate Pad (part of the Deluxe Harness kit) also features a built-in Storage Pak and provides additional padding if desired.

Alternative lift devices include Diver Alert Markers (safety sausages), Surf Shuttles, Lift Bags, and the Halcyon Diver's Life Raft. A complete list of Halcyon lift devices is available in this manual's appendix.



Figure 35

WEIGHTING YOUR HALCYON BC SYSTEM

The Halcyon Buoyancy Compensator provides for quick and easy adjustment of your ballast. Once properly fitted, your Harness and backplate can be used with any of the Halcyon single-cylinder wings or double-cylinder wings, with only minor adjustments of the harness to account for different exposure suits and by the selection of the appropriate weighting system. The goal of any SCUBA configuration is to create a system that allows a diver control at both the beginning and end of a dive.

Proper weighting involves balancing a number of factors, including: increased surface buoyancy (particularly in a neoprene suit before compression); the weight of your breathing supply (reduced as the dive continues); and the need to remain neutral at 10' (3m), assuming near empty cylinder (or cylinders). Typically, more than 80% of the weight a diver wears to sink a neoprene suit is needed only within the first atmosphere. At depth, compression of the material forces the diver to offset the reduction in lift with additional buoyancy. Furthermore, divers must ensure sufficient weight to counteract empty cylinders near the surface where the neoprene suit is not compressed and will begin to exert additional lift.

Halcyon's BC system has the flexibility to allow divers a range of weighting options to achieve proper balance; these options include the Active Control Ballast™ (ACB) integrated weight system (figure 36), canister lights, v-weights (placed beneath the back plate on doubles), weighted single tank adapters, backplates in stainless or aluminum, Halcyon Trim Weights (placed on the back of a single tank), and/or the use of a traditional weight belt. For example, an Eclipse system might be configured with a combination of releasable and fixed ballast. Six pounds (3 kg) of fixed ballast are accounted for with the Halcyon stainless-steel backplate.

You may also adjust non-releasable weighting by choosing Halcyon's aluminum backplate or the weighted Halcyon Single Tank Adapter (6 lb/2.7 kg) (figure 37 on the following page). An additional two to ten pounds (1-4 kg) can be positioned directly on your tank using Halcyon's Trim Weight pockets (figure 38-39). When properly configured and tested, tank trim weighting may assist in facilitating a heads-up position while at the surface. However, you should not consider the BC system as a replacement for a life jacket; it is not designed to function in this capacity. Proper placement of tank-mounted Halcyon Trim Weights also promotes stable and consistent horizontal trim during the dive. The remainder of the necessary weighting can be fine-tuned through the use of Halcyon's ACB integrated weight system, configurable with up to 20 pounds (9 kg) of releasable weight.



Figure 36



CAUTION: IT IS IMPORTANT NOT TO OVERWEIGHT THE DIVING RIG WITH TOO MUCH FIXED WEIGHT; THIS CONFIGURATION MAY NOT ALLOW SUFFICIENT REMOVABLE WEIGHT, PREVENTING THE DIVER FROM "DITCHING" THE WEIGHT AND SWIMMING TO THE SURFACE DURING AN EMERGENCY.



CAUTION: YOU SHOULD BE CERTAIN THROUGH IN-WATER TESTING PRIOR TO A DIVE THAT, WITHOUT ANY AIR IN YOUR BUOYANCY COMPENSATOR, YOU ARE CAPABLE OF SWIMMING AGAINST THE WEIGHT OF YOUR CONFIGURATION WITH FULL TANKS AND ALL WEIGHT IN PLACE. YOU NEED TO VERIFY THAT YOU ARE ABLE TO MANAGE YOUR SCUBA CONFIGURATION IN THE EVENT OF A BUOYANCY FAILURE.

MATCHING YOUR WING TO THE PROPER CYLINDER

With the appropriate balanced rig, the Eclipse 30-lb. (13.6-kg) and the Eclipse 40-lb. (20.2-kg) wing are both designed for light to medium weight aluminum and steel single cylinders, such as a single 20-litre or aluminum-80 cylinder.

Halcyon's Explorer double cylinder wings are available in 40-lb (20.4-kg) and 55-lb. (25-kg) lift sizes; the Evolve wings are available in either 40-lb. (20-kg) or 60-lb. (27-kg) lift sizes. The Explorer and Evolve 40 wings are primarily designed for use with double aluminum-80 (10-liter) cylinders. The Explorer 55 and Evolve 60 wings are suitable for use with a wide range of aluminum and



steel double cylinders, including 12/15 litre and 95/104 cubic foot steel cylinders. The Evolve 60 is suitable for twin 20-litre cylinders.

Explorer and Evolve wings should not be used in any single-cylinder configuration.

ASSEMBLY OF BC SYSTEM WEIGHTING OPTIONS

Halcyon offers a variety of ways to weight your BC system. Fixed-weight options include the Convertible 6-lb. weight that fits into the Single Tank Adapter (figure 37), and of course the choice of the 6-lb. SS backplate or the 2-lb. aluminum backplate. In addition, our Trim Weight pockets are designed to be attached to the Single Tank Adapter (STA) cam straps, providing 5 lb. per pocket of additional fixed ballast on your System (figure 38-40).



Figure 37



Figure 38



Figure 39



Figure 40

ASSEMBLY OF THE STA WITH CONVERTIBLE 6LB WEIGHT

1. Disassemble your BC System so the STA is separate from the BC. Save these STA bolts for use when diving without your Convertible weight, and keep the fasteners and bolt retaining washers* for use after assembly.
2. Remove, or loosen, the cam straps to place the convertible weight into the STA channel.
3. Insert the weight into the channel, placing the bolts through the STA bolt holes. Replace cam straps.
4. Reassemble your BC system by placing the bolts back through the wing and backplate then secure with the bolt holder and fasteners. Be sure to securely tighten the STA bolt fasteners and check them before each dive.

**Halcyon's Single Tank Adapter now features a set of plastic retaining washers on the STA bolts to keep the bolts in place on the STA when assembling your gear.*

To complement the use of fixed weight to create a "balanced rig," we offer ACB Integrated Weight Pockets. These are designed to replace the need for a conventional weight belt. The ACB is comprised of two weight pockets attached to the harness waist belt. Each pocket features an internal pocket, with handle, for convenient transport between dives. The left pocket has an integrated D-ring that replaces the D-ring on the harness. Both pockets have a simple,

and secure tri-glide attachment to the waist band to prevent the pockets from sliding forward while you are in a proper horizontal swimming position.

ATTACHING THE ACB INTEGRATED WEIGHT SYSTEM TO YOUR SECURE HARNESS

1. If needed, separate the backplate/harness from the wing.
2. Remove the buckle and D-ring from the left side of the waist strap.
3. Start with the right pocket and thread it through the triglide on the pocket and onto the right waist strap. The buckle and handle of the weight pocket should be pointing to the front of you on the ACB20, or downward with the ACB10 style pockets.
4. The left pocket is then threaded through the tri-glide on the pocket and onto the left side waist strap with the handle facing the front of you. Notice that the D-ring on the left ACB weight pocket replaces the original left hip D-ring.
5. Replace the buckle on the left waist strap.
6. Loading weights into the pockets is very simple. Remove the inner weight pocket and add the desired amount of soft or solid lead weight. Replace the inner pocket. We suggest fastening the outer buckle through the weight pocket handle.
7. Secure each buckle before your dive.

RELEASING THE ACB INTEGRATED WEIGHT POCKETS

To remove the weight pockets, release the buckles on the outer pockets and slide the inner pockets out and away from your body. Make certain that the weighted inner pockets are free from any entanglements, then release (see images below).



PRE-DIVE

BC SYSTEM INSPECTION

Before each use, the BC must be given a thorough visual inspection and functional test. Never dive with a BC that shows signs of damage to its bladder or valving until it has received a complete inspection and service from an Authorized Halcyon Dealer. Periodically it is advised to check the buoyancy compensator OPV for damage or corrosion and the Secure Harness webbing for signs of wear. If your Secure Harness shows significant wear at the shoulder or waist slots on the backplate, replace the webbing before diving.

INSPECTION CHECKLIST

1. Connect the wing's power inflator to a clean air source, via the LP quick-disconnect hose. Depress and release the inflator button intermittently to ensure that the airflow is unobstructed, and that the airflow stops completely when the button is released.
2. Manually operate the overpressure (OP) valve by pulling on the attached string to test spring and valve integrity. Fully inflate the buoyancy wing until the OP valve opens. Regular inspection of the OP valve for corrosion or damage is recommended.
3. Examine the operation of the OP valve by repeatedly inflating the wing to ensure that the valve opens to relieve excess pressure, yet closes immediately afterward to allow the bladder to remain taut and fully inflated.
4. Check the function of the oral inflator button, rapid exhaust valve, and overpressure/manual dump valve to ensure a rapid and unobstructed exhaust from each valve. Listen closely for any leakage with the wing fully inflated but not connected to a low-pressure air source. If there is any suspicion of leak, submerge and, once equalized to depth, check for continued bubbling.



WARNING: IF ANY LEAKAGE CAN BE HEARD, OR IF THE BLADDER BEGINS TO DEFLATE WITHIN 5-10 MINUTES, DO NOT ATTEMPT TO USE THE BC UNTIL IT HAS RECEIVED FACTORY PRESCRIBED SERVICE FROM AN AUTHORIZED HALCYON DEALER.

5. Make a final check of tension of both cam straps on the SCUBA cylinder to ensure that they have not loosened due to stretching. Confirm tightness of fastener bolts that attach the backplate to the Single Tank Adapter if diving singles, or to the double-tank bands if diving dual cylinders. Retighten as necessary.
6. Before entering the water, check both ACB system pockets to ensure that they are correctly fastened to the BC with the Fastex buckles.



WARNING: LOSS OF THE ACB SYSTEM POCKETS CAN OCCUR IF THE BUCKLES ARE NOT SECURELY LATCHED. UNINTENTIONAL RELEASE OF BOTH WEIGHT POCKETS UNDERWATER MAY LEAD TO AN UNCONTROLLED ASCENT, AND COULD RESULT IN SERIOUS INJURY OR DEATH.

BC SYSTEM

CARE AND MAINTENANCE

With proper care, your Halcyon BC will provide many years of reliable service. The following preventative maintenance must be performed to extend the life of your BC.

PREVENTATIVE MAINTENANCE

Avoid repeated or prolonged use in heavily chlorinated water. Prolonged exposure to chemically treated water can damage the BC's material.

Do not allow the BC's wing to chafe against any sharp objects or rough surfaces that could abrade or puncture the bladder. Do not set or drop heavy objects, such as block weights, on the BC's wing. Store the wing partially inflated to reduce the possibility of puncture.

Avoid prolonged exposure to direct sunlight and extreme heat. Nylon fabric may fade when exposed to the sun's ultraviolet rays, and extreme heat may damage the integrity of the BC's welded seams.

Avoid any contact with oil, gasoline, or other solvents or contaminants.



CAUTION: RECOMMENDED WORKING PRESSURE OF THE HALCYON BC INFLATOR IS 120 PSI (8.3 BAR) TO 160 PSI (11 BAR)



CAUTION: OPERATING TEMPERATURE RANGE OF THE HALCYON BC SYSTEM IS -20 CELSIUS (-4 FAHRENHEIT) TO 70 CELSIUS (158 FAHRENHEIT). ALL PRUDENT/KNOWN SAFEGUARDS AND PROCEDURES SHOULD BE OBSERVED WHEN DIVING IN NEAR OR SUB-FREEZING TEMPERATURES ON THE SURFACE AND BELOW.

POST-DIVE MAINTENANCE

To prevent permanent damage from corrosion, salt crystals, or chlorine attack, thoroughly rinse the BC inside and out with fresh water after every day of use, using the following procedure:

1. Pressurize the power inflator with low-pressure air, via the quick-disconnect hose.
2. Using a garden hose or other fresh water source, direct water through the oral inflator to flush the interior of the bladder, and then thoroughly rinse the exterior of the BC.



CAUTION: BEFORE RINSING, ENSURE THAT THE POWER INFLATOR IS PRESSURIZED WITH AIR. THIS WILL PREVENT FOREIGN PARTICLES AND CONTAMINATION FROM ENTERING THE VALVE MECHANISM IN THE EVENT THAT THE INFLATOR BUTTON IS ACCIDENTALLY DEPRESSED.

3. Completely drain the bladder of water, either through the oral inflator or through the over pressure valve, being careful to avoid operating the power inflator.
4. Inflate the BC and allow it to dry inside and out before storing. Store the BC partially inflated, away from direct sunlight, and in a cool, dry, clean area.

APPENDIX I

BUOYANCY COMPENSATOR SYSTEM COMPONENTS

BUOYANCY WINGS

TYP / STYLE	AUFTRIEB / BUOYANCY	AUFTRIEBSRATE / INFLATION RATE N/S	AUSLASSRATE / DEFLATION RATE N/S
TRAVELER	30	11.2	110
TRAVELER PRO 20	20	8.9	87
TRAVELER PRO 30	30	12.2	120
TRAVELER PRO 40	40	16.3	160
ECLIPSE 20	20	8.9	87
ECLIPSE 30	30	13.1	129
ECLIPSE 40	40	15.3	150
EVOLVE 40	40	18.9	185
EVOLVE 60	60	23.4	230
EVOLVE JJ	32	15	147
EXPLORER 40	40	17.3	170
EXPLORER 55	55	24.9	244
EXPLORER CCR	35	13.3	130
CONTOUR S	35	14.6	143
CONTOUR	40	18.6	186

ALTERNATE LIFE AND SURFACE MARKING DEVICES

BC Storage Pak for alternate lift device

Big Diver's Alert Marker, 4.5' long, 40-lb. (18 kg) lift, with OPV

Super Diver's Alert Marker, 5.9' long, 52-lb. (23.6 kg) lift, with OPV

Small Diver's Alert Marker, Closed Circuit with SS D-ring

Lift Bag 80-lb. (36.3 kg), Closed Circuit with OPV

SECURE HARNESS ACCESSORIES

Stainless Steel Backplate (standard or small size)

Harness & Knife Pocket (with adj. crotch strap)

Aluminum Backplate (standard or small size)

Harness & Knife Pocket (with adj. crotch strap)

Right Zippered Pocket (attaches to harness strap)

Stainless Knife for Halcyon Harness Knife Pocket

Deluxe Harness Pads (shoulder and backplate)

WEIGHTING SYSTEMS

ACB 10 Integrated Weight Pockets - 5 lb. (2.2 kg) per side
Trim Weight Kit w/ releasable ballast (10 lb./4.5 kg max)
Weighted Single Tank Adapter, 6 lb. (2.7 kg)

GEAR BAGS

Gear Bag, Textilene / Cordura®

HALCYON GUIDELINE DEVICES

Defender Delrin safety/gap/jump spools
Coldwater Defender jump spools
Pathfinder Primary Reels, 400', 800' versions (122, 244 meters)

HALCYON LIGHTING SYSTEMS

Explorer 10 and 21 watt HID/NiMH Systems
Apollo Video Lighting Systems
Scout Back-up Lights in LED

APPENDIX II

WARRANTY INFORMATION

WARRANTY INFORMATION

All warranty requests must be accompanied by proof of original purchase from an Authorized Halcyon Dealer. Be sure to save your sales receipt, and present it whenever returning your BC for warranty service.

HALCYON warrants, to the original purchaser only, that the HALCYON Buoyancy Compensator will be free of defects in materials and/or craftsmanship under normal diving use for one year from the date of purchase, provided proper care is performed on all materials as described within this manual. Should your HALCYON BC prove to be defective for any reason (other than those listed in the limitations section below) it will be repaired or replaced (at HALCYON's discretion) free of charge excluding shipping and handling charges. All correspondence concerning this warranty must be accompanied by a copy of the original sales receipt. Repair or replacement is HALCYON's only responsibility and your only remedy under this warranty.



WARNING: IT IS DANGEROUS FOR UNTRAINED AND INCERTITUDE PERSONS TO USE THE EQUIPMENT COVERED BY THIS WARRANTY. THEREFORE, USE OF THESE PRODUCTS BY AN UNTRAINED PERSON RENDERS ANY AND ALL WARRANTIES NULL AND VOID. USE OF SCUBA EQUIPMENT BY ANYONE WHO IS NOT A CERTIFIED DIVER, OR RECEIVING TRAINING THROUGH A RECOGNIZED AGENCY, SHALL RENDER VOID ALL WARRANTIES, EXPRESSED OR IMPLIED.

ALL WARRANTIES, INCLUDING, BUT NOT LIMITED TO, IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE LIMITED IN DURATION TO A PERIOD ENDING ONE YEAR FROM THE DATE OF PURCHASE.

Some states in the U.S. and certain foreign countries do not allow limitations on the duration of implied warranties, so this may not apply to you. This warranty gives you specific legal rights. You may have rights that vary from state to state and country to country.

HALCYON MANUFACTURING DISCLAIMS AND EXCLUDES ANY LIABILITY FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES. SOME STATES IN THE U.S. AND CERTAIN FOREIGN COUNTRIES DO NOT ALLOW EXCLUSIONS OR LIMITATIONS OF LIABILITY FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THIS MAY NOT APPLY TO YOU.

The following restrictions apply to this warranty.

1. This warranty extends to all power inflator parts and to the seams of the BC wing bladder.
2. This warranty does not extend to abrasion, punctures, or tears of the bladder, or seam separation caused by chemical attack, including prolonged exposure to chlorine.

3. This warranty does not extend to damages caused by improper use, improper maintenance, neglect, unauthorized repairs, modifications, accidents, fire, or casualty.
4. Cosmetic damage, such as scratches, fraying, and nicks are not covered by this warranty.
5. This warranty does not extend to equipment used for rental, commercial, governmental, or military purposes.
6. This warranty covers products purchased in the United States. For warranties that may apply elsewhere, please contact your local representative.
7. Failure to meet any of the above requirements will render the warranty null and void.

APPENDIX III

DECLARATION OF HARMFUL SUBSTANCES (German / English)

Artikel / Article: Buoyancy Compensator Devices

Hersteller or Inverkehrbringer* / Manufacturer or person who put the product to the market:
Halcyon Manufacturing Inc.

Straße / Street: 24587 NW 178th Place

Land, PLZ, Ort / Location: High Springs, Florida USA 32643

Ansprechpartner / Contact: Mark Messersmith

Telefon-Nr. / Phone no.: +1 386 454 0811

Fax-Nr. / Fax no.: +1 386 454 0815

E-Mail / E-mail: mm@halcyon.net

Hiermit wird durch den Hersteller und/oder Inverkehrbringer bestätigt, dass der Artikel keine gesundheitsgefährdenden Konzentrationen von Stoffen gemäß Verordnung (EU) 2016/425 Anh. II, Abs. 1.2.1.1. und nach Anhang XIV und XVII der Verordnung (EG) Nr. 1907/2006 (REACH) enthält.

Darüber hinaus wird die Einhaltung weitergehender gesetzlicher Anforderungen zu Schadstoffen in Erzeugnissen in Deutschland bestätigt (z.B. Verbote von PCP, Chrom-VI ...) und es werden auch die Anforderungen hinsichtlich polyzyklischer aromatischer Kohlenwasserstoffe (PAK) gemäß AfPS GS 2014:01 PAK eingehalten. Der Hersteller bestätigt, dass die PSA aus Materialien hergestellt sind, die die Gesundheit oder Hygiene des Anwenders nicht beeinträchtigen. Die Materialien setzen unter den voraussehbaren normalen Anwendungsbedingungen oder durch ihren Abbau keine Substanzen frei, die allgemein als toxisch, karzinogen, mutagen, allergen, reproduktionstoxisch oder auf andere Weise schädlich bekannt sind.

Bei der Herstellung des Artikels wurden keine / folgende (Unzutreffendes bitte streichen) bioziden oder flammhemmenden Ausrüstungen verwendet.

Die Sicherheitsdatenblätter der Ausrüstungen sind beizufügen!

The manufacturer and / or the person who puts the product in the market is confirms, that the article contains no health impairing concentrations of substances according to Regulation (EU) 2016/425, annex II, 1.2.1.1. and to Annex XVI and XVII of Regulation (EC) No. 1907/2006 (REACH).

In addition we confirm compliance with legal requirements for harmful substances in Germany (e.g. ban of PCP, Chromium-V I...) and that requirements for polyaromatic hydrocarbons (PAH) to

AfPS GS 2014:01 PAK are also met. The manufacturer confirms that the PPE is made from materials which do not affect the health or hygiene of the user. We also confirm that the PPE is made of materials that under foreseeable conditions of normal use or by degradation do not release substances generally known to be toxic, carcinogenic, mutagenic, allergenic, toxic to reproduction or otherwise harmful.

In the manufacture of the article no biocide or flame retarding finishings were used.

Fragebogen zum Produktionsablauf / Questionnaire regarding the production process

Wareneingang / Receiving area

1. Gibt es einen Verantwortlichen für den Bereich Wareneingang? X ja / yes Is there a responsible person for the receiving area?
- nein / no

2. Welche Wareneingangsprüfungen werden bzgl. der zertifizierten Produkte durchgeführt? / What receiving inspections are performed in regards to certified products?

- All components used in the making of our products are received into our warehouse. The count is verified and compared to the packing list and invoice. Components are then quality checked for visual and functional defects according to product specifications.

3. Werden Fertigungsverfahren regelmäßig überwacht und die zugehörigen QM-Dokumente überprüft (Verfahrensaudits?) X ja / yes Are the procedures used in the manufacturing process regularly monitored and the related documents verified?
- nein / no
Our Production Manager and Quality Control Manager are closely involved with all steps of the production process. Measuring and evaluating the production results as they compare to specifications.

4. Werden Zwischenprüfungen im Produktionsprozeß durchgeführt X ja / yes Are in-process-inspections performed?
- nein / no
Quality Control responsibilities include spot check, random check and final check of all products. In fact, all products that contain air for buoyancy are tested over night to confirm proper performance.

Endprüfungen / Final testing

1. Werden Endprüfungen durchgeführt? X ja / yes Are final-inspections performed?
- nein / no

2. Werden die Prüfergebnisse dokumentiert und nachgewiesen? X ja / yes Are the test results documented and verified?
- nein / no
Werden die Ergebnisse der Auswertungen an das Management? X ja / yes weitergegeben? Are the results reported regularly to upper management? nein / no

3. Wird das prüfende und überwachende Personal entsprechend? X ja / yes

Artikel / Article: Buoyancy Compensator Devices

Hersteller or Inverkehrbringer* / Manufacturer or person who put the product to the market:
Halcyon Manufacturing Inc.

Straße / Street: 24587 NW 178th Place

Land, PLZ, Ort / Location: High Springs, Florida USA 32643

Ansprechpartner / Contact: Mark Messersmith

Telefon-Nr. / Phone no.: +1 386 454 0811

Fax-Nr. / Fax no.: +1 386 454 0815

E-Mail / E-mail: mm@halcyon.net

Hiermit wird durch den Hersteller und/oder Inverkehrbringer bestätigt, dass der Artikel keine gesundheitsgefährdenden Konzentrationen von Stoffen gemäß Verordnung (EU) 2016/425 Anh. II, Abs. 1.2.1.1. und nach Anhang XIV und XVII der Verordnung (EG) Nr. 1907/2006 (REACH) enthält.

Darüber hinaus wird die Einhaltung weitergehender gesetzlicher Anforderungen zu Schadstoffen in Erzeugnissen in Deutschland bestätigt (z.B. Verbote von PCP, Chrom-VI ...) und es werden auch die Anforderungen hinsichtlich polyzyklischer aromatischer Kohlenwasserstoffe (PAK) gemäß AfPS GS 2014:01 PAK eingehalten. Der Hersteller bestätigt, dass die PSA aus Materialien hergestellt sind, die die Gesundheit oder Hygiene des Anwenders nicht beeinträchtigen. Die Materialien setzen unter den voraussehbaren normalen Anwendungsbedingungen oder durch ihren Abbau keine Substanzen frei, die allgemein als toxisch, karzinogen, mutagen, allergen, reproduktionstoxisch oder auf andere Weise schädlich bekannt sind.

Bei der Herstellung des Artikels wurden keine / folgende (Unzutreffendes bitte streichen) bioziden oder flammhemmenden Ausrüstungen verwendet.

Die Sicherheitsdatenblätter der Ausrüstungen sind beizufügen!

The manufacturer and / or the person who puts the product in the market is confirms, that the article contains no health impairing concentrations of substances according to Regulation (EU) 2016/425, annex II, 1.2.1.1. and to Annex XVI and XVII of Regulation (EC) No. 1907/2006 (REACH).

In addition we confirm compliance with legal requirements for harmful substances in Germany (e.g. ban of PCP, Chromium-V I...) and that requirements for polyaromatic hydrocarbons (PAH) to AfPS GS 2014:01 PAK are also met. The manufacturer confirms that the PPE is made from materials which do not affect the health or hygiene of the user. We also confirm that the PPE is made of materials that under foreseeable conditions of normal use or by degradation do not release substances generally known to be toxic, carcinogenic, mutagenic, allergenic, toxic to reproduction or otherwise harmful.

In the manufacture of the article no biocide or flame retarding finishings were used.

Fragebogen zum Produktionsablauf / Questionnaire regarding the production process

Wareneingang / Receiving area

1. Gibt es einen Verantwortlichen für den Bereich Wareneingang? X ja / yes Is there a responsible person for the receiving area?
- nein / no
2. Welche Wareneingangsprüfungen werden bzgl. der zertifizierten Produkte durchgeführt? / What receiving inspections are performed in regards to certified products?

- All components used in the making of our products are received into our warehouse. The count is verified and compared to the packing list and invoice. Components are then quality checked for visual and functional defects according to product specifications.
3. Werden Fertigungsverfahren regelmäßig überwacht und die zugehörigen QM-Dokumente überprüft (Verfahrensaudits?) X ja / yes Are the procedures used in the manufacturing process regularly monitored and the related documents verified?
- nein / no
Our Production Manager and Quality Control Manager are closely involved with all steps of the production process. Measuring and evaluating the production results as they compare to specifications.
4. Werden Zwischenprüfungen im Produktionsprozeß durchgeführt X ja / yes Are in-process-inspections performed?
- nein / no
Quality Control responsibilities include spot check, random check and final check of all products. In fact, all products that contain air for buoyancy are tested over night to confirm proper performance.

Endprüfungen / Final testing

1. Werden Endprüfungen durchgeführt? X ja / yes Are final-inspections performed?
- nein / no
2. Werden die Prüfergebnisse dokumentiert und nachgewiesen? X ja / yes Are the test results documented and verified?
- nein / no
Werden die Ergebnisse der Auswertungen an das Management? X ja / yes weitergegeben? Are the results reported regularly to upper management? nein / no
3. Wird das prüfende und überwachende Personal entsprechend? X ja / yes seiner Aufgabe unterwiesen?
- nein / no

Is there appropriate training for the inspection and testing personnel?

Sind die Unterweisungen dokumentiert und nachgewiesen? X ja / yes Are training records documented and verified?
- nein / no

NOTES

NOTES



CONTACT US



24587 NW 178TH PLACE
HIGH SPRINGS, FLORIDA 32643



P. 386.454.0811 or 1-800-HALCYON
F. 386.454.0315



INFO@HALCYON.NET
WWW.HALCYON.NET